



This image illustrates the minimal amount of effort the operator requires to maintain control of a 38lb Level IV shield. Shield Support Systems can be custom designed for the weight of ballistic protection being supported.

# THE REAPER™ SHIELD SUPPORT

- Individual Shield or Shield and Weapon Support
- Supports the weight of up to level IV ballistic shield, allowing the operator to utilize a rifle or sidearm
- Increased efficiency & endurance
- Load transfer from arms & shoulders to torso and hips
- Quick release system if shield no longer required
- Carry higher levels of protective shields without increased load on arms
- Allows operator 360° maneuverability
- Allows for reload behind the shield (shield dependent)
- Hold shield in position for extended periods of time



The Reaper™ Shield Support attaches to the operator using molle pouches to body armor or with standalone Mystery Ranch and ADA Pack Frames systems.



Operator can push shield outwards towards threat and retract.



The Reaper™ Shield Support allows for 360° rotation of the shield and can independently support the weight of the shield, should the operator be required to utilize both hands.



Includes universal shield strap that connects directly to The Reaper Shield Support™ quick release.



- Designed to be worn over body armor
- Uses same molle pouches that can be used on belt and body armor
- Adjustable to fit any body size
- Systems available in black multi cam, multi cam or desert
- Can be configured to carry entry tools, TCCC gear, extra comms
- Works well for use with lighter shields
- Can fit over soft armor systems